




# INSTALLATION INSTRUCTIONS: JEEP WRANGLER JL/JLU BATTLE READY ALUMINUM INNER FENDER KIT, REAR - DRAFT

 <b>Parts List</b>	
1	Pair Rear Inner Fender Liners
1	Installation Hardware Bag
1	Installation Instructions

## Difficulty Level : Medium



## Product Support



## PRODUCT IMAGE

 <b>Tool List</b>	
10 mm Wrench	4 mm Allen Key
8 mm Socket	Ratchet
Drill	1/4" Drill Bit
Trim Removal Tool	



## NOTES AND MAINTENANCE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

For black finishes, mild soap may be used to clean the product.

Periodic inspections should be performed to ensure all mounting hardware remains tight.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

## FEEDBACK

COMBAT OFF ROAD industry leading warranty. Register your purchase by visiting: [www.combat-offroad.com/registration](http://www.combat-offroad.com/registration)

Be social, tag us on your install or out on the trail enjoying, use: #combatoffroad

## DISCLAIMER

Jeep®, Wrangler, Rubicon, and the Jeep grille design are registered trademarks of FCA (Fiat Chrysler Automobiles). Combat Off Road has no affiliation with FCA. The terms Jeep®, Wrangler, MOPAR®, & Rubicon are used for identification purposes only.

## STEP 1

Remove the existing inner fender liner

Using a suitable trim removal tool, pry out the 8 securing plastic pins at the locations shown at the circled area

Using the drill and ¼" bit, drill out the center of the plastic rivets around the outside perimeter that joins the inner fender to the outer flare

Repeat for opposite side of vehicle



## STEP 2

Install mounting strips

There is a unique design for driver side vs passenger side, locate the correct one for the side of the vehicle you are working on, see images for reference.

Install the speed clips at the 2 locations shown on each mounting strip.

Bolt the mounting strip to the vehicle using the existing 3 hole locations on the body. Use the supplied bolts, washers and nuts at each location and tighten with the 4 mm Allen key and 10 mm wrench.

NOTE: Some adjustment of the strip may be required to align the holes with the body.



Passenger Side



Driver Side



### STEP 3

Assemble the inner fender pieces together on a suitable work surface.

Use the supplied bolts, washers and nuts at each location and tighten with the 4 mm Allen key and 10 mm wrench.

Install speed clips as shown in the circled locations, these will be used to secure to the vehicle body later during the installation.



Passenger Side Assembly



Driver Side Assembly

## STEP 4

Assemble the inner fender onto the vehicle

Align the inner fender with the mounting holes and the existing outer fender retaining clips

Use the supplied bolts and washers at the 2 upper and 2 lower mounting locations where the speed clips were installed in the previous steps. Tighten with the 4 mm Allen key.



Passenger Side Completed



Driver Side Completed